

Changing the LR44 battery :



1. Insert your fingernail into the small dip located on the top zone of the front face .
2. Remove the thermometer's mask by pushing towards you (gently) and reveal the battery's location and motherboard.

3. Loosen one of the two small metallic clips that keep the battery into place.



4. Insert new battery with bottom part up (writing of the battery needs to be up) and reposition the small metallic clip that you just turned away, into it's original position, in order to ensure best stability of the battery.

5. Reattach the mask onto the thermometer's main body into the same way it was originally inserted. Make sure that the wires were not moved much during the process. Also make sure the wires are inserted all the way to the end of the sensor's stainless steel adapter, by making the wires stay straight before insertion process, so that way it's tip will surely touch the end of the adapter, just as we mentioned above.

6. Done !



**BLU STAR COFFEE**