

## **OBSIDIAN AQUA**

### **Solution A**

Distilled Water	300 ml	350 ml	700 ml
Sodium Metabisulphite	8 g	10 g	20 g
Catechol	100 g	125 g	250 g
Distilled Water to make	400 ml	500 ml	1 litre

### **Solution B (Concentrate)**

Distilled Water	4 litres
Sodium Carbonate Anhydrous	1 kilo
Distilled Water to make	5 litres

### **Working Solution**

Solution A	1 ml	1.2 ml	2 ml
Solution B	12.5 ml	15 ml	25 ml
<b>Tap Water to make</b>	<b>500 ml</b>	<b>600 ml</b>	<b>1 litre</b>