



American Wheat Beer

Documento oficial de Caribbean Brewing

AMERICAN WHEAT BEER

A familiar style made popular by microbreweries all over the US. Like their German cousins, American wheat beers feature large proportions of malted wheat in the grain bill and are naturally cloudy in appearance.

Unlike

German Weizenbiers, though, American wheat beers have a bit more hop character and are fermented with a milder-tasting yeast, resulting in a more clean, neutral finish. Wyeast's US Hefeweizen strain makes for a spritzzy, refreshing warm-weather crowd-pleaser.

O.G: 1.043 READY: 4 WEEKS

2 weeks primary, 2 weeks bottle conditioning

KIT INVENTORY:

FERMENTABLES

- 6 lbs Wheat malt syrup

BOIL ADDITIONS

- 1 oz Willamette (60 min)

- 1 oz Cascade (15 min)

YEAST

- WYEAST 1010 AMERICAN WHEAT

YEAST. A dry fermenting, true top cropping yeast which produces a dry, slightly tart, crisp beer, in American hefeweizen style.

Apparent attenuation: 74-78%.

Flocculation: low. Optimum

temp: 58°-74° F.

- DRY YEAST ALTERNATIVE: Safale US-05 Ale Yeast.

Optimum temp: 59°-75° F

These simple instructions are basic brewing procedures for this Caribbean Brewing extract beer kit; please refer to your starter kit instructions for specific instructions on use of equipment and common procedures such as siphoning, sanitizing, bottling, etc.

For more detailed extract brewing instructions, please

visit www.caribbeanbrewing.com

BEFORE YOU BEGIN ...

MINIMUM REQUIREMENTS

- Homebrewing starter kit for brewing 5 gallon batches

- Boiling kettle of at least 3.5 gallons capacity

- Approximately two cases of either 12 oz or 22 oz pry-off style beer bottles

UNPACK THE KIT

- Refrigerate the yeast upon arrival

- Locate the Kit Inventory (above) – this is the recipe for your beer, so keep it handy

- Doublecheck the box contents vs. the Kit Inventory

- Contact us immediately if you have

any questions or concerns!

PROCEDURE

A FEW DAYS BEFORE BREWING DAY

1. Remove the liquid Wyeast pack from the refrigerator, and "smack" as shown on the back of the yeast package. Leave it in a warm place (70-80° F) to incubate until the pack begins to inflate. Allow at least 3 hours for inflation; some packs may take up to several days to show inflation. Do not brew with inactive yeast — we can replace the yeast, but not a batch that fails to ferment properly. If you are using dry yeast, no action is needed.

ON BREWING DAY

2. Collect and heat 2.5 gallons of water.

3. Bring to a boil and add 6 lb Wheat malt syrup. Remove the kettle from the burner and stir in the Wheat malt syrup.

4. Return wort to boil. The mixture is now called "wort", the brewer's term for unfermented beer.

- Add 1 oz Willamette hops, and boil for 60 minutes.

- Add 1 oz Cascade hops 15 minutes before the end of the boil.

5. Cool the wort. When the 60-minute boil is finished, cool the wort to approximately 100° F as rapidly as possible.

Use a wort chiller, or put the kettle in an ice bath in your sink.

6. Sanitize fermenting equipment and yeast pack. While the wort cools, sanitize the fermenting equipment – fermenter, lid or stopper, fermentation lock, funnel, etc – along with the yeast pack and a pair of scissors.

7. Fill primary fermenter with 2 gallons of cold water, then pour in the cooled wort. Leave any thick sludge in the bottom of the kettle.

8. Add more cold water as needed to bring the volume to 5 gallons.

9. Aerate the wort. Seal the fermenter and rock back and forth to splash for a few minutes, or use an aeration system and diffusion stone.

10. Measure specific gravity of the wort with a hydrometer and record.

11. Add yeast once the temperature of the wort is 78°F or lower (not warm to the touch). Use the sanitized scissors to cut off a corner of the yeast pack, and carefully pour the yeast into the primary fermenter.

12. Seal the fermenter. Add approximately 1 tablespoon of water to the sanitized fermentation lock. Insert the lock into rubber stopper or lid, and seal the fermenter.

13. Move the fermenter to a warm, dark, quiet spot until fermentation begins.

AMERICAN WHEAT BEER BEYOND BREWING DAY, WEEKS 1-2

14. Active fermentation begins. Within approximately 48 hours of Brewing Day, active fermentation will begin – there will be a cap of foam on the surface of the beer, the specific gravity as measured with a hydrometer will drop steadily, and you may see bubbles come through the fermentation lock. The optimum fermentation temperature for this beer is 58-74° F – move the fermenter to a warmer or cooler spot as needed.

15. Active fermentation ends.

Approximately two weeks after brewing day, active fermentation will end. When the cap of foam falls back into the new beer, bubbling in the fermentation lock slows down or stops, and the specific gravity as measured with a hydrometer is stable, proceed to the next step.

BOTTLING DAY—ABOUT 2 WEEKS AFTER BREWING DAY

16. Sanitize siphoning and bottling equipment.

17. Mix a priming solution (a measured amount of sugar dissolved in water to carbonate the bottled beer). Use the following amounts, depending on which type of sugar you will use:

- Corn sugar (dextrose) 2/3 cup in 16 oz water.

- Table sugar (sucrose) 5/8 cup in 16 oz water.

Then bring the solution to a boil and pour into the bottling bucket.

18. Siphon beer into bottling bucket and mix with priming solution. Stir gently to mix—don't splash.

19. Fill and cap bottles.

2 WEEKS AFTER BOTTLING DAY

20. Condition bottles at room temperature for 2 weeks.

After this point, the bottles can be stored cool or cold.

21. Serving. Pour into a clean glass, being careful to leave the layer of sediment at the bottom of the bottle.